

PIVOT™

Better Connection. Better Protection.
*Making the **Case** for Aviation.*

**Airbus A318/319/320/321
Long Term Removable Mount
LTRM
Installation and Removal Manual**



| | | | |
|---|----------------------|----------------------|---------------|
| Document no. LTRM Manual PM-A319-20-21-CA FO_Rev_0_02 NOV 2018 | Revision 0 | Date Nov 02, 2018 | Page 2 (4) |
|---|----------------------|----------------------|---------------|

Read Before Use

For optimal performance and maximum satisfaction with your PIVOT product, please follow this set of simple instructions to ensure proper deployment.

Purpose

This document provides the necessary information for the correct and placement and removal of the PIVOT LTRM Mount for the Airbus A320 series aircraft so to ensure its safe use and operation.

Extent

This instruction manual is appropriate for all personnel involved in the placement and/or removal of PIVOT LTRM mount.

Reference / Definitions

- LTRM Long Term Removable Mount
- CA Captain’s Side Mount (PM-A319-20-21-CA)
- FO First Officer’s Side Mount (PM-A319-20-21-FO)



Responsibility

PIVOT reserves the right to make changes to meet new specifications at any time without incurring any obligation to modify previously installed units. This manual is provided for informational and reference purposes only and is subject to change without notice. Service Bulletins may be issued separately and their effect on this manual will be made evident by reissue of the appropriate list of Service Bulletins. This document can only be changed by an authorized PIVOT engineer.

Illustrations

All visuals in this document are examples being used for explanatory purposes and are not intended to be exact depictions of original parts as described in this document and are subject to change without notice.

Overview

The PIVOT LTRM Mount consists of several parts:

- Contoured attachment plate
- High-deflection AMPS adapter with PPK-1 mounting plate

Total installation time for a shipset (CA and FO) should not exceed 10 minutes. Installation does not require the use of any tools and can be realized by accomplishing the steps which are detailed on the following pages.

| | | | |
|---|----------------------|----------------------|---------------|
| Document no. LTRM Manual PM-A319-20-21-CA FO_Rev_0_02 NOV 2018 | Revision 0 | Date Nov 02, 2018 | Page 3 (4) |
|---|----------------------|----------------------|---------------|

LTRM Installation Instructions

For either the CA or FO position, hold the appropriate CA or FO PIVOT LTRM in one hand, gripping the vertical mount structure with your thumb and forefinger.



With your other hand, lift the clipboard clamp on the window shroud.



With the clipboard clamp raised, slide the mount under the raised clamp and place the top edge of the mount securely into the window shade slot.



Press down and clip the lower edge of the mount structure onto the window coving. The installation is complete.



Attachment & Removal of PIVOT Case to LTRM

Refer to PIVOT Case User Guide for details.

LTRM Removal Instructions

For either the CA or FO LTRM, grasp the PIVOT mounting plate by gripping it with your thumb and forefinger.



Using your other hand, lift the lower edge of the mount up and away from the window coving.



Once it is separated from the coving, lift the top edge away from the window shade slot. The removal is complete.



Additional Information

To learn more, please visit pivotcase.com for instructional videos, product support and additional information about PIVOT products. You'll find valuable online resources provided to enhance your user experience and see the complete line of PIVOT products.

If you have questions, please contact PIVOT Support.



www.pivotcase.com/support



sales@pivotcase.com



1-888-4-FLYBOYS (1-888-435-9269)
Outside the U.S.A.: 281-895-0128



www.youtube.com/c/pivotcasevideo

PIVOTTM
Better Connection. Better Protection.
Making the Case for Aviation.

TM and © 2018 FlyBoys Inc. All rights reserved. Designed in USA. Printed in USA.