

USER GUIDE **PIVOT** **DKS ADAPTER**





Better Connection. Better Protection.
*Making the **Case** for Aviation.*

DKS Adapter | User Guide

Read Before Use

Your PIVOT case is designed to provide superior device protection while combining functionality and aesthetics. Following the recommendations in this guide will ensure maximum performance with proper use of the DKS Adapter.

Parts

Aircraft Docking Station (ADKS), preinstalled Thales mount with power

PIVOT/Thales Docking Station (DKS) adapter

PIVOT Case

Power cord with USB-A Male




360° Adjustability



Easy Setup



Click! Connection



Future Proof

Installing

STEP 1: Slide the PIVOT DKS Adapter onto the Thales Docking Station. Ensure that the adapter is firmly and securely in place on the electrical pins on the top edge of the Docking Station.




STEP 2: If power to the tablet is required, locate the USB-A ports on the DKS Adapter. Insert charging cable as needed.



Pro Tip!

There are two ports available.

STEP 3: Attach your PIVOT case to the DKS adapter by aligning the mounting channel above the mounting plate and guiding the case onto the mounting plate. Your case is properly installed when you hear an audible “CLICK” when the case engages with the mounting plate. If you do not hear an audible “CLICK”, the case may not be properly installed.



WARNING! The mounting plate should slide smoothly into the case mounting channel with very little resistance. If you encounter resistance, the mounting plate may be misaligned. Do not force the case on to the mount or damage may occur. Gently remove the case from the mounting plate, confirm correct alignment, and reattempt installation.



Did You Know?

PIVOT's unique mounting systems are universal and interchangeable, ensuring your PIVOT case will securely connect to every standard PIVOT mount: past, present, and future.

STEP 4: Once the PIVOT case is installed, connect charging cable to the iPad as needed.



Rotate

To convert to horizontal or vertical position.



Removing

PIVOT case should be in portrait orientation to access clip.

STEP 1: Unplug charging cable from the device.



STEP 2: Press the PIVOT Clip to disconnect the PIVOT case from the mounting plate and slide the tablet to the side to remove it from the DKS adapter.



The PIVOT DKS Adapter does not need to be removed from the Thales Docking Station. We suggest you leave the adapter in place on the aircraft. However, if removal is desired, press the tab on the Docking station (ADKS) and slide up to remove the DKS adapter from the ADKS Docking station.



Thank you.

Additional Information

To learn more about your PIVOT case, please visit pivotcase.com for instructional videos, product support and additional information about PIVOT products. You'll find valuable online resources provided to enhance your user experience and see the complete line of PIVOT products.

Learn more at:
PIVOTCASE.COM

PIVOT SUPPORT

If you have questions please contact PIVOT Support.



www.pivotcase.com/support



sales@pivotcase.com



1-888-4-FLYBOYS (1-888-435-9269)



www.youtube.com/c/pivotcasevideo

TM and © 2023 FlyBoys. All rights reserved.
Designed in USA.

PIVOT®

Better Connection. Better Protection.
*Making the **Case** for Aviation.*